

## Water Chlorination in Pressure Networks / High Pressure Pumping Stations / Wells

- Chlorination in pressure networks, high pressure pumping stations and wells.
- In some places injecting (sodium or calcium) hypochlorite is usual for disinfecting water from wells in the well-head in order to use the transport time to the treatment plant.
- The use of equipment able to inject against high network pressures is often needed.

**ITC Products: Dostec 40, Mixer**



**DOSTEC 40**  
**DOSING PUMP**



**CHEMICAL**  
**MIXER**